


IIOT for Advanced Manufacturing (ECMC104)

Lab 8 – Configuring a Data Visualisation Package

Objectives

1. To install and configure the open-source InfluxDB, which is a time-series database.
2. To install and configure the open-source Grafana, which is a web-based data visualisation package.
3. To configure Grafana with alert monitoring on data.

IoT Case Study: Global Environmental Monitoring



“uRADMonitor is a project that addresses pollution, the kind that we are unable to see, but directly affects our health and can cause life-threatening diseases. To help fight pollution, we have designed several fixed and mobile detectors, packed with powerful sensors, capable of detecting both the chemical and the harmful physical factors. All data goes online to a global network, so anyone can access it freely, at any time.”

Source:

<https://cleantechnica.com/2015/12/11/uradmonitor-global-pollution-tracking-network/>
<https://www.uradmonitor.com/>

Carry out a research to find out:


- What is the purpose of Data Visualization in Internet of Things(IoT)?
- Explain the importance of the role that Data Visualization plays in the uRADMonitor project. How would it be like if there is no element of Data Visualization in this project?

Contents

1	Introduction to TICK	3
2	InfluxDB for Time-Series Data Storage	3
2.1	Download and Install InfluxDB Package	3
2.2	Configuration	5
2.3	Testing InfluxDB	5
2.4	Install InfluxDB Python Client	6
2.5	Write a InfluxDB Python Program	6
2.5.1	Create a Database	6
2.5.2	Write the Program	8
2.5.3	Testing the Program	11
3	Grafana for Dashboard and Metrics Monitoring	11
3.1	Install Package	11
3.2	Starting the Grafana Service	12
3.3	Setting up Grafana to read from InfluxDB	12
3.4	Challenge	21

1 Introduction to TICK

InfluxDB (I) is part of the “**TICK**” stack. The complete stack offers a complete solution to IoT applications. In this exercise, besides InfluxDB, we will also be exploring the **C** (for **Chronograf**) of TICK. This is a visualisation application. For this exercise, we will be using **Grafana** instead of Chronograf as Grafana has added advantages to use different databases, besides InfluxDB.



InfluxDB is part of the “**TICK**” stack

2 InfluxDB for Time-Series Data Storage

References:

<https://docs.influxdata.com/influxdb/v2.4/>

2.1 Download and Install InfluxDB Package

Launch the WSL2/Ubuntu Terminal.

Create a folder, **/home/<user>/Develop/Lab7** folder. This folder will store all your download and program codes for this lab.

Download the InfluxDB package from the web with the following command:

```
$ wget https://dl.influxdata.com/influxdb/releases/influxdb2-2.4.0-amd64.deb --no-check-certificate
```

* You may check for the latest version of InfluxDB at the download page and amend the command accordingly: <https://portal.influxdata.com/downloads>.

You should observe an output similar to the following if the package is successfully downloaded:

```
--2022-12-12 14:57:10-- https://dl.influxdata.com/influxdb/releases/influxdb2-2.4.0-amd64.deb
```

```

Resolving dl.influxdata.com (dl.influxdata.com)... 143.204.9.73, 143.204.9.2,
143.204.9.88, ...
Connecting to dl.influxdata.com (dl.influxdata.com)|143.204.9.73|:443...
connected.
WARNING: cannot verify dl.influxdata.com's certificate, issued by 'CN=Zscaler
Intermediate Root CA (zscaler.net) (t)\ ,OU=Zscaler Inc.,O=Zscaler
Inc.,ST=California,C=US':
  Unable to locally verify the issuer's authority.
HTTP request sent, awaiting response... 200 OK
Length: 92102818 (88M) [application/vnd.debian.binary-package]
Saving to: 'influxdb2-2.4.0-amd64.deb'

influxdb2-2.4.0-amd64.deb
100%[=====>] 87.84M
3.02MB/s in 17s

2022-12-12 14:57:34 (5.17 MB/s) - 'influxdb2-2.4.0-amd64.deb' saved
[92102818/92102818]

```

Next, install the package:

```
$ sudo dpkg -i influxdb2-2.4.0-amd64.deb
```

You should observe the following output:

```

Selecting previously unselected package influxdb2.
(Reading database ... 42152 files and directories currently installed.)
Preparing to unpack influxdb2-2.4.0-amd64.deb ...
Unpacking influxdb2 (2.4.0-1) ...
Setting up influxdb2 (2.4.0-1) ...
Created symlink /etc/systemd/system/influxd.service →
/lib/systemd/system/influxdb.service.
Created symlink /etc/systemd/system/multi-user.target.wants/influxdb.service →
/lib/systemd/system/influxdb.service.

After installation, the output observes will be:
new Debian package, version 2.0.
 size 92102818 bytes: control archive=2499 bytes.
    26 bytes,  1 lines   conffiles
   317 bytes, 14 lines   control
   481 bytes,  7 lines   md5sums
  3852 bytes, 142 lines * postinst             #!/bin/bash
  1475 bytes,  58 lines * postrm              #!/bin/bash
   428 bytes, 22 lines * preinst               #!/bin/bash

Package: influxdb2
Version: 2.4.0-1
License: MIT
Vendor: InfluxData
Architecture: amd64
Maintainer: support@influxdb.com
Installed-Size: 146654
Depends: curl
Conflicts: influxdb
Recommends: influxdb2-cli
Section: default
Priority: extra
Homepage: https://influxdata.com
Description: Distributed time-series database.

```

2.2 Configuration

Add the InfluxData repository (you can try to understand this as being part of the required configuration) with the following commands:

```
$ sudo curl -sL https://repos.influxdata.com/influxdb.key | sudo apt-key add -  
$ sudo echo "deb https://repos.influxdata.com/ubuntu bionic stable" | sudo tee  
/etc/apt/sources.list.d/influxdb.list
```

Hint:

The first command requires the **curl** utility. You will be asked to install with the following command if **curl** has not been installed yet:

```
$ sudo apt install curl
```

Upon completing all the 3 commands above, this will create a file called “/etc/apt/sources.list.d/influxdb.list” if it worked.

Next, install and start the InfluxDB service:

```
$ sudo apt-get update  
$ sudo apt-get install influxdb  
$ sudo influxd &
```

To check whether the service is started, type the following command:

```
$ sudo service influxdb status
```

This will give you the following output if InfluxDB is started successfully;

```
● influxdb.service - InfluxDB is an open-source, distributed, time series database  
   Loaded: loaded (/lib/systemd/system/influxdb.service; enabled; vendor preset: enabled)  
   Active: active (running) since Mon 2026-01-05 08:49:38 +08; 1h 25min ago  
     Docs: man:influxd(1)  
    Main PID: 199 (influxd)  
      Tasks: 17 (limit: 9138)  
    Memory: 64.4M  
       CPU: 13.057s  
    CGroup: /system.slice/influxdb.service  
            └─199 /usr/bin/influxd -config /etc/influxdb/influxdb.conf
```

Install InfluxDB client:

```
$ sudo apt install influxdb-client
```

2.3 Testing InfluxDB

To test that the installation is done correctly, connect to **InfluxDB** with this command:

```
$ influx
```

The following output should be observed:

```
Connected to http://localhost:8086 version 1.6.7~rc0  
InfluxDB shell version: 1.6.7~rc0  
>
```

Type **quit** to exit from the InfluxDB command line prompt:

```
> quit
```

2.4 Install InfluxDB Python Client

References:

<https://github.com/influxdata/influxdb-python>
<https://influxdb-python.readthedocs.io/en/latest/>

InfluxDB works with a number of languages – one of them is Python. In order to use Python, it is necessary to install the **InfluxDB-Python** client library or package.

Run the following command to install this package:

```
$ sudo apt install python3-influxdb
```

2.5 Write a InfluxDB Python Program

With all the above set up, you are now ready to write a simple program to perform writing to the InfluxDB database.

2.5.1 Create a Database

Launch the **Terminal** program. Run the InfluxDB command line program with the following command:

```
$ influx
```

```
Connected to http://localhost:8086 version 1.5.1
InfluxDB shell version: 1.5.1
>
```

At the prompt, type:

```
> help
```

This shows you a condensed list of commands you can execute:

```
> help
Usage:
    connect <host:port>    connects to another node specified by host:port
    auth                  prompts for username and password
    pretty                 toggles pretty print for the json format
    chunked                turns on chunked responses from server
    chunk size <size>      sets the size of the chunked responses.
                           Set to 0 to reset to the default chunked size
    use <db_name>          sets current database
    format <format>        specifies the format of the server responses: json, csv, or column
    precision <format>     specifies the format of the timestamp: rfc3339, h, m, s, ms, u or ns
    consistency <level>    sets write consistency level: any, one, quorum, or all
    history                displays command history
    settings               outputs the current settings for the shell
    clear                  clears settings such as database or retention policy.
                           run 'clear' for help
    exit/quit/ctrl+d      quits the influx shell
```

```
show databases      show database names
show series         show series information
show measurements   show measurement information
show tag keys       show tag key information
show field keys     show field key information
```

A full list of influxql commands can be found at:
https://docs.influxdata.com/influxdb/latest/query_language/spec/

At the prompt, type:

```
> show databases
```

This gives you the current databases which have been created so far.

```
name: databases
name
----
_internal
>
```

To create a new database with the name **mydb**, type:

```
> create database mydb
```

Type the following again to confirm that it has been created:

```
> show databases
```

You should see the following output:

```
name: databases
name
----
_internal
mydb
>
```

Type **quit** to exit from the InfluxDB command line prompt:

```
> quit
```

2.5.2 Write the Program

Create the folder, `/home/<user>/Develop/Lab7`. This will be the folder where you will store all your program codes for this lab.

Exercise 1:

Edit the following program and save it as `writedb.py`.

```
1 import argparse
2 from influxdb import InfluxDBClient
3 from influxdb.client import InfluxDBClientError
4 import datetime
5 import time
6 import random
7
8 USER = 'root'
9 PASSWORD = 'root'
10 DBNAME = 'mydb'
11 HOST = 'localhost'
12 PORT = 8086
13 dbclient = None;
14
15 def main():
16     dbclient = InfluxDBClient(HOST, PORT, USER, PASSWORD, DBNAME)
17     while True:
18         data_point = getSensorData()
19         dbclient.write_points(data_point)
20         print("Written data")
21         time.sleep(2)
22
23
24 def getSensorData():
25     sensorData = random.randint(15, 40)
26     now = time.gmtime()
27     pointValues = [
28         {
29             "time": time.strftime("%Y-%m-%d %H:%M:%S", now),
30             "measurement": 'reading',
31             "tags": {
32                 "nodeId": "node_1",
33             },
34             "fields": {
35                 "value": sensorData
36             },
37         }
38     ]
39
40     return(pointValues)
41
42 if __name__ == '__main__':
43     main()
```

writedb.py

The following points explain the important parts of the program:

- **Creating a Client Object:**

The function, **InfluxDBClient()** is used to create a client instance.

Explore this library function:

```
class influxdb.InfluxDBClient(host=u'localhost', port=8086, username=u'root',  
password=u'root', database=None, ssl=False, verify_ssl=False, timeout=None,  
retries=3, use_udp=False, udp_port=4444, proxies=None)
```

For more details on this function - **InfluxDBClient()**, go to the URL below:

<https://influxdb-python.readthedocs.io/en/latest/api-documentation.html#influxdbclient>

Question:

- 1) Using what you have learnt in **Lab 5** on named and optional arguments in a Python function, how many optional arguments are there in this function?
- 2) What is the default value for the argument, **host**?
- 3) What is the default value for the argument, **port**?

- **Writing Data:**

The function, **write_points()** is used to write data into the database.

Explore this library function:

```
write_points(points, time_precision=None, database=None, retention_policy=None,  
tags=None, batch_size=None, protocol=u'json')
```

For more details on this function - **write_points()**, go to the URL below:

https://influxdb-python.readthedocs.io/en/latest/api-documentation.html#influxdb.InfluxDBClient.write_points

It is important to note that the first parameter, **points** is a Python **list**. More specifically, it is a **list** of dictionaries. Each dictionary represents a point to be written. In other words, **points** refers to a list of points to be written to the database.

Question:

- 1) Using what you have learnt in **Lab 5** on named and optional arguments in a Python function, how many optional arguments are there in this function?
- 2) What is the default value for the argument, **protocol**?

- **JSON Data Structure:**

As you have seen in **Lab 4 Section 2.2**, **pointValues** is a **JSON data structure**.

```
pointValues = [
    {
        "time": time.strftime("%Y-%m-%d %H:%M:%S", now),
        "measurement": 'reading',
        "tags": {
            "nodeId": "node_1",
        },
        "fields": {
            "value": sensorData
        },
    }
]
```

Fill in the blanks below. Refer to **Lab 2 – Python & Raspberry Pi**.

Questions:

- 1) In the above, **pointValues** is a Python _____ object.
- 2) However, **pointValues** contain only _____ element in the _____ object.
- 3) This _____ is a _____ object.
- 4) This _____ object contains _____ main key-value pairs, with the keys as “time”, “measurement”, “tags” and “fields”. This _____ object is a _____ with the _____ “tags” and “fields”.

- **InfluxDB Key Concepts:**

Please read the following to understand the key concepts of InfluxDB.

Reference:

<https://docs.influxdata.com/influxdb/v2.4/reference/key-concepts/>

Questions:

- 1) As InfluxDB is a time-series database, it is necessary to have the _____ column. All InfluxDB data has this column.
- 2) The **measurement** is conceptually similar to a database _____.
- 3) _____ values are the data. They can be string, float, integers or Boolean.
- 4) The _____ in the above example is _____. And the **field-value** is the variable - **sensorData**.
- 5) As tags are indexed, this makes queries faster. It is optional to use tags. In the above example, the **tag-key** is the _____; while the **tag-value** is **node_1**.

Note: This example illustrates the sensor data from **node_1**. In a scaled-up example, sensor data can come from multiple nodes. It is important to know which node does it comes from.

2.5.3 Testing the Program

Run the program with the following command:

```
$ python3 writedb.py
```

<https://docs.influxdata.com/influxdb/v2.4/>

You may refer to the link for for the latest update.

We can either enter the InfluxDB interactive prompt to view the data, or execute a command at the command line using the command line interface (CLI) described above to view the data. If using the CLI, you can execute:

```
$ influx -database 'mydb' -execute 'select * from reading'
```

You can also export the readings to a file (in this case, **mydata.csv** in csv format) by executing the following command:

```
$ influx -database 'mydb' -execute 'select * from reading' -format 'csv' >> mydata.csv
```

3 Grafana for Dashboard and Metrics Monitoring

References:

<http://docs.grafana.org/installation/debian>

Grafana is a visualisation package that can be configured to work with InfluxDB.

3.1 Install Package

First, open the **Terminal** program and path to **'/home/<user>/Develop/Lab7'** you created earlier.

Download the Grafana package from the web with the **wget** command:

```
$ wget https://dl.grafana.com/oss/release/grafana_9.3.1_amd64.deb --no-check-certificate
```

At the point of writing, the version of Grafana is 9.3.1.

The following will be observed. The downloading may take a few minutes depending on your internet speed.

```

Resolving dl.grafana.com (dl.grafana.com)... 151.101.54.217, 2a04:4e42:d::729
Connecting to dl.grafana.com (dl.grafana.com)|151.101.54.217|:443... connected.
ERROR: cannot verify dl.grafana.com's certificate, issued by 'CN=Zscaler Intermediate Root CA
(zscaler.net) (t)\ ,OU=Zscaler Inc.,O=Zscaler Inc.,ST=California,C=US':
  Unable to locally verify the issuer's authority.
To connect to dl.grafana.com insecurely, use '--no-check-certificate'.
iotp@ENG-R90YT61T-10:~/Develop/lab6/grafana$ wget
https://dl.grafana.com/oss/release/grafana_9.3.1_amd64.deb --no-check-certificate
--2022-12-12 16:38:39-- https://dl.grafana.com/oss/release/grafana_9.3.1_amd64.deb
Resolving dl.grafana.com (dl.grafana.com)... 151.101.54.217, 2a04:4e42:d::729
Connecting to dl.grafana.com (dl.grafana.com)|151.101.54.217|:443... connected.
WARNING: cannot verify dl.grafana.com's certificate, issued by 'CN=Zscaler Intermediate Root
CA (zscaler.net) (t)\ ,OU=Zscaler Inc.,O=Zscaler Inc.,ST=California,C=US':
  Unable to locally verify the issuer's authority.
HTTP request sent, awaiting response... 200 OK
Length: 88725002 (85M) [application/octet-stream]
Saving to: 'grafana_9.3.1_amd64.deb'

grafana_9.3.1_amd64.deb
100%[=====>] 84.61M 5.36MB/s
in 48s

2022-12-12 16:39:33 (1.75 MB/s) - 'grafana_9.3.1_amd64.deb' saved [88725002/88725002]

```

Next, install Grafana with the following 2 commands:

```

$ sudo apt-get install -y adduser libfontconfig
$ sudo dpkg -i grafana_9.3.1_amd64.deb

```

3.2 Starting the Grafana Service

Start the Grafana server:

```

$ sudo service grafana-server start

```

Configure the service daemon in the operating system so that the Grafana service starts every time upon booting up:

```

$ sudo systemctl enable grafana-server.service

```

This is what you will observe:

```

$ sudo systemctl enable grafana-server.service
Synchronizing state of grafana-server.service with SysV service script with
/lib/systemd/systemd-sysv-install.
Executing: /lib/systemd/systemd-sysv-install enable grafana-server
$

```


3.3 Setting up Grafana to read from InfluxDB

References:


<https://grafana.com/docs/grafana/latest/>


In the **Chrome** browser, go to **localhost:3000**. Grafana uses port 3000 to serve its web pages.

Log in as (user) **admin**, and (password) **admin**.




When ask to change new password, **Skip** for now.







Click the  icon and **Data sources**. This brings you to the following settings page:



Click **Add data source**:



Select InfluxDB:




Under the **Settings** tab, enter the following information for the appropriate fields:

- Name: Temperature Sensor Reading

HTTP:


- URL: <http://localhost:8086>




Scroll down to **InfluxDB Details**:


- Database: mydb
- User: root
- Password: root

Click the **Save & Test** button next. If the parameters are set correctly, you will see a message – “**data source is working. 1 meaurement found**”.






Click the  icon.




Select **Add a new panel**.




This brings you to **New dashboard /Edit Panel** page.

Scroll below and Select the **Query** tab page. Provide the following settings:

- **Data Source:** Temperature Sensor Data
- **FROM -> select measurement:** reading



Click **Apply** on the top-right hand corner of the same page when you are done.




The panel should now be populated with the data that you have generated from the running of your Python script **writedb.py** earlier in **Exercise 1**.

Ponder:

Why is 'reading' selected for "select measurement"?

Save your dashboard by clicking on the **save** icon at the top of the screen. Provide a name for the dashboard when prompted.




Select the drop-down menu **Panel Title** -> **Edit**.

Exercise 2:

1. Give proper labels to the panel title.

Click **Panel options** > **Title** and give an appropriate Panel Title.



2. Scroll further down to **Connect null values**.

- Select **Always**

Observe the graph convert from dotted point to connecting line.

- Click **Apply**



3. Enable the graph to automatically refresh every 5 seconds.

- Click the  **5s** icon at top right of screen.

- Select **5s**



4. Allow the Python script to continue running and observe the Grafana chart.
In terminal window, issue the command: **python3 writedb.py**


3.4 Challenge

Grafana Alerting alerts you to problems in your system moments after they occur. Create, manage, and act on your alerts in a single, consolidated view, and improve the ability to identify and resolve issues quickly.

Exercise 3: Setting up an Alert for Monitoring

- Click the **Alert** tab at bottom panel of **My dashboard / Edit Panel**.

Enter the condition for the alert to be activated; such as when the temperature is above certain threshold. What did you observe in the graph when the condition is set?



Do you notice a heart shape symbol besides the panel title which indicate the health of your system after you set the Alert?

- Normal  Temperature Sensor Reading
- Pending  Temperature Sensor Reading
- Alerting  Temperature Sensor Reading

Demonstrate to your tutor.

Online resource to create alert in Grafana:

<https://grafana.com/docs/grafana/latest/alerting/>

<https://www.youtube.com/watch?v=h2daQ8mQ2pM>

~ End of Lab 8 ~